



Summary

The following software shows how to suppress the "ok" prompt.

```
\ Copyright 1998 Mosaic Industries, Inc. All rights reserved.
\ This source code implements a standard forth interpreter (typically
\ named QUIT), and allows the user to comment out and suppress the "ok" prompt.
\ All multitasking and error trapping functions of the standard interpreter
\ are preserved. Works for QED kernel versions V3.1x and V4.0x.

4 USE. PAGE \ not needed if memory map has already been set
ANEW NOT. OK. STUFF \ forget marker

\ ***** CONSTANT AND VARIABLE DECLARATIONS *****

PARITY 6 XN- XCONSTANT LOCALS. ARE. COMPILING
\ system variable, zeroed on entry to interpreter

TRANSMITTING 2XN- XCONSTANT ACTIVE. SERIAL
\ system variable, holds addr of SERIAL1 or SERIAL2 resource variable;
\ set by USE. SERIALx, used by interpreter to get and release

TRACE DROP (STATUS) - 2+ USER TRACE. INDENT
\ a byte-sized user variable, = #spaces indented by TRACE; zeroed by QUIT

\ ***** PRIMITIVES *****

: *RELEASE. SERIAL ( -- )
\ if permission flag in user variable SERIAL. ACCESS is >= RELEASE. AFTER. LINE,
\ then go ahead and release it; otherwise, don't.
\ if resource is released, we PAUSE to give others access to the resource.
\ serial.access values are: release.never {0}; release.after.line{1};
\ or release.after.char {2}
SERIAL. ACCESS @ RELEASE. AFTER. LINE >=
IF ACTIVE. SERIAL @ DEFAULT. PAGE RELEASE
PAUSE \ give other tasks a shot at serial line
ENDIF
;
```

```

: GET. SERIAL. FOR. LINE ( -- )
  \ if serial.access contains RELEASE.AFTER.LINE,
  \ GETs the in.use serial resource. Otherwise does nothing. Called by QUIT.
  SERIAL.ACCESS @ RELEASE.AFTER.LINE =
  IF ACTIVE.SERIAL @ DEFAULT.PAGE GET
  ENDIF
;

: *OK? ( -- ) \ ok prompt is commented out.
  \ at end of interpretation line, prints 'ok' and prints stack if needed
  \ used by QUIT and BREAK;
  \ aborts on dstack underflow, does COLD if SO isn't in common ram
  \ if allowed by +SERIAL.ACCESS flag, and if we're executing,
  \ releases serial resource variable {SERIAL1.RESOURCE or SERIAL2.RESOURCE,
  \ whichever is in use} at the end of the line
  \ and pauses to give other tasks a chance to use serial.
  STATE @ 0=
  IF \ if we're executing...
  \ SPACE ." ok" \ commented out to suppress ok print!!
  \ DEBUG @ \ if debug flag is set...
  IF DEPTH 0<> \ if items are on dstack...
  \ IF .S ENDIF \ ...print stack; aborts on dstack underflow
  ENDIF
  *RELEASE.SERIAL ( -- ) \ release & pause to give other tasks a chance
  ENDIF
;

\ ***** THE INTERPRETER *****

\ Note: any errors that cause an ABORT will terminate the execution
\ of FORTH.INTERPRETER. To automatically re-enter the customized interpreter,
\ post a customized abort handler as described in appendix B of the
\ Forth software manual. For example:
\ : MY.ABORT.ACTION
\ SP! RP! FORTH.DEFINITIONS FORTH.INTERPRETER ;
\ CFA.FOR.MY.ABORT.ACTION UABORT X! \ install new action
\ CUSTOM.ABORT.ON \ set flag so custom abort is called.

: FORTH.INTERPRETER ( -- ) \ replacement for QUIT, the standard interpreter.
\ infinite loop, terminated by error-induced ABORTs.
  [COMPILE] [ \ set execution mode {set state = 0 }
  LOCALS.ARE.COMPILED OFF \ clear locals. are. compiling
  0 TRACE.INDENT C! \ clear #spaces indented by TRACE
  BEGIN
    STATE @ 0=
    IF RP! ENDIF
    CR \ issue carriage return & line feed
    QUERY \ read a line of text into TIB, init 0= >IN = BLK
    INTERPRET \ move 1 line to pocket and interpret; check dstack
    *OK? \ ok prompt is commented out in this routine.
    GET.SERIAL.FOR.LINE \ get if RELEASE.AFTER.LINE is specified
  AGAIN \ this is an infinite loop, terminated by errors
;

```

The information provided herein is believed to be reliable; however, Mosaic Industries assumes no responsibility for inaccuracies or omissions. Mosaic Industries assumes no responsibility for the use of this information and all use of such information shall be entirely at the user's own risk.

Mosaic Industries

5437 Central Ave Suite 1, Newark, CA 94560

Telephone: (510) 790-8222

Fax: (510) 790-0925